

Tilt navigation on the Samsung Instinct

Mobile browsing has never been so convenient.

What is it?

Tilt navigation or motion browsing is an easy new way to browse websites using the Samsung Instinct.

What it does?

By just tilting the phone you can easily navigate and quickly find areas of interest while browsing a web site.

Why is it better?

Tilt navigation gives the mobile user the freedom and speed to browse websites on the go quickly.

When used in combination with finger touch and haptics (vibrating tactile feedback), you can find information faster and avoid the risk of inadvertently clicking on a link while panning with finger touch. Once you have found the information you are looking for, you use your finger to hone in on exactly the information you need.


How to use it?

Once the Instinct browser is launched, press and hold the camera button to pan inside a web site...

Press camera button



...by tilting right and left...



...up and down.

Release the camera button, when you want to stop panning.